

POWER DISTRIBUTION UNIT



Product Name	Part No.	Description
Power distribution unit 50A	DPU0502-3-1	<ol style="list-style-type: none"> 1.Circuit breaker input: 1*50A/2P 2.UPS input: 1*40A/1P 3.UPS output:1*32A/1P 4.UPSmaintenance:1*32A/1P(wihtlock) 5.UPSoutputbranchswitch:2*32A/1P(forPDU1andPDU2) 6.UPSoutputbranchswitch:2*10A/1P(forSupervisionSystemandlightningsystem) 7.Mainselectricityoutputswitch:1*10A/1P(airconditioner),1*20A/1P(back up) 8.Lightningprotectioncircuitbreaker:1*32A/2P 9.Support monitoring PUE data by intellgient electricity meter 10.Schneider switch
Power distribution unit 50A	DPU0501-3-2	<ol style="list-style-type: none"> 1.Circuit breaker input: 1*50A/1P 2.UPS input: 1*40A/1P 3.UPS output:1*32A/1P 4.UPSmaintenance:1*32A/2P(wihtlock) 5.UPSoutputbranchswitch:4*16A/1P(forPDU1,PDU2,PDU3andPDU4) 6.UPSoutputbranchswitch:2*10A/1P(forSupervisionSystemandlightningsystem) 7.Mains electricity output switch: 1*10A/1P(air conditioner), 1*20A/1P(back up) 8.Lightningprotectioncircuitbreaker:1*32A/2P 9.Support monitoring PUE data by intellgient electricity meter 10.Schneider switch
Power distribution unit 80A	DPU0801-6-3	<ol style="list-style-type: none"> 1.Circuit breaker input: 1*80A/1P 2.UPS input: 1*63A/1P 3.UPSoutput:1*52A/1P 4.UPSmaintenance:1*50A/2P(wihtlock) 5.UPSoutputbranchswitch:6*16A/1P(forPDU1-PDU6) 6.UPSoutputbranchswitch:2*10A/1P(forSupervisionSystemandlightningsystem) 7.Mainselectricityoutputswitch:2*10A/1P(airconditioner),2*20A/1P(back up) 8.Lightningprotectioncircuitbreaker:1*32A/2P

		<p>9.Support monitoring PUE data by intelligient electricity meter</p> <p>10.Schneider switch</p>
--	--	---